Mini LED Light

Operation: Push thumbwheel forward to light, on two color modles, toggle switch left /right to select LED color.

Low Battery Indication: white, green, blue LEDs require more voltage than red or infrared LEDs and will fade first. How to change the battery:

- Depress latch tab by pressing bump next to thumbwheel, rotate cap out and down to remove.
- 2) Remove circuit board and battery.
- Detach battery from circuit board and attach new 9 volt.
- 4) Insert circuit board and battery into body.
- Insert hinge tab into hinge hole (see picture below) and pivot cap upward around hinge until latched.

